



PUT UP PRE-GLUED WALLPAPER

NECESSARY MATERIAL: sponge – spray bottle– ruler – brush – cutter – squeegee* – plumb line – tape (adhesive paper) - cloth

IMPORTANT : For best results, give preference to light and unified walls. We recommend reactivating the glue at the back of the wallpaper from top to bottom by zones of 50 to 60 cm.

1. Use the cloth to **clean the wall**

2. In order to position your strip, use the tape to stick the wall and the strip together. Put the tape 50 cm from the top. (we recommend a paper tape with low adhesion in order not to tear the paper apart)

NB: If your wall is not straight, use the **plumb line** technique in order to position your strip correctly.

3. **Fold the upper part of the strips of 50 cm. Spray water at the back of the paper** (upper part). Spray the wall as well, but not too much! Water should be vaporized on the entire surface until the extremity of the paper but be careful not to make it soggy. If you're putting up a non-washable paper, do not put water on the printed part of the paper.

4. Apply the paper to the wall and create a grip. **Press over with the brush.**

5. With the **squeegee**, make the paper stick to the angles.

6. **Delicately, take the scotch off.** Make sure that the paper **adheres** well enough before proceeding to next step.

7. **Repeat the operation** by zones of 50 cm (+/-) until the bottom of the wall.

8. **Position the second strips** while **matching the patterns together.** Repeat the first strip's steps.

9. When the paper is dry, **cut the overage** with the **cutter** and the **ruler.**

WATCH OUR TUTORIAL TO HELP:

www.youtube.com/watch?v=yol6xezmTGo



PAPERMINT

Ask us question at:
serviceclient@paper-mint.fr

*For sales on paper-mint.fr